


INSTAR Heater for IN-2908 UPGRADE PACK DUICH INSTAllation Guide

Content of delivery: 1x Heating Element IN-2908, 1x Quick Installation Guide

INSTAR Deutschland GmbH hereby ensures that you will not lose your warranty by installing this additional heater. **ATTENTION**: Any damages caused by the user by faulty installation are excluded of the warranty.









Move the top cover a little by gently pulling it to the direction of the lense. Use an Allen Key to remove the 2 screws in the back plate of the camera (Fig. 1). Carefully pull the back plate and the mainboard from the camera body and unplug the board from the sensor unit (Fig. 2).

Loosen the 2 screws which holds the mainboard to get easier access to the connector (Fig. 3). Now you should be able to unplug the **13-pin** power cable connector from the mainboard (**Fig. 4**).





Now plug the heater element to the now vacant connector on the mainboard (Fig. 5). Then connect the other end of the cable from the heating element with the 13-pin power supply (Fig. 6). Please make sure that all plugs are properly connected. To reassemble the camera you will need to reattach the mainboard to the back cover (Fig. 3) and reconnect the mainboard with the sensor unit. (Fig. 2).



Place the back plate back onto the housing and ensure that the **O-Ring**, which seals the camera and protects it from water is still in place. The thermostat (silver unit, Fig. 7) has to point away from the mainboard! Fasten the back plate using the 2 screws from Fig. 1 and slide the top cover back to its original position (Fig. 1).